



<p>Restricted Flow (RFT)</p>		<ul style="list-style-type: none"> • Thermal gate for small pin point vestige with stringing materials like polypropylene, polyamide and polyester • Available in two versions for amorphous and crystalline materials as plunge through tips with 4mm and 8mm contact • Ideal for wear materials • Hot tip version with insulator bubble for fast cycling, thin wall applications that require optimum gate appearance
<p>Open Flow (OFT)</p>		<ul style="list-style-type: none"> • Thermal gate with small button vestige for non-stringing materials such as ABS, SB, PE, talcum filled PP, PMMA, etc. • Available in two versions for amorphous and crystalline materials as plunge through tips with 4mm and 8mm contact to the gate steel
<p>Valve Flow (VFT)</p>		<ul style="list-style-type: none"> • Zero gate vestige • Ideal for parts that require a high quality surface, large gate orifice for large shot volume, a long pack time for dimensional control, positive gate shut-off, sequential or cascade cavity fill • Ideal for abrasive, filled and fiber reinforced materials • Valve version with insulator bubble for fast cycling, thin wall parts with optimum surface appearance • Ideal for amorphous materials, as well as PP and PE
<p>Edge Gate (HEG)</p>		<ul style="list-style-type: none"> • Side gating into part walls • Ideal for PP, PE, PS and non-color change applications